

Rauch- und Geruchsentwicklung

Vor der ersten Benutzung

Am Heizelement befindet sich eine Schutzschicht, die beim Aufheizen des Gerätes verbrennt. Dadurch kann es bei der Benutzung des Gerätes zu einer geringen Rauch- und Geruchsentwicklung kommen, welche jedoch nach einigen Nutzungsvorgängen abklingen. Dies stellt keinen Mangel dar.

- Sofern das Heizelement frei zugänglich ist, können Sie diese Rauchentwicklung minimieren, indem Sie das Heizelement vor der ersten Benutzung mit einem leicht angefeuchteten Tuch abwischen.
- Benutzen Sie **keine** Reinigungsmittel!
- Wischen Sie mit einem trockenen Tuch nach.
- Schalten Sie das Gerät nur in einem vollkommen **trockenen** Zustand ein.
- Sorgen Sie immer für ausreichende Belüftung.

Smoke and Odour Development

Before the First Use

There is a protective layer on the heating element which burns when the device is heated up. This can cause a slight development of smoke and odour when using the appliance, which however will subside after a few use cycles. This is not a defect.

- If the heating element is freely accessible, you can minimize this smoke development by wiping the heating element with a slightly moistened cloth before the first use.
- Do **not** use any cleaning agents!
- Wipe with a dry cloth.
- Only switch on the device when it is **completely dry**.
- Always ensure sufficient ventilation.